1829057
Monaco Card Table

Parts List

A.	Top Assembly	1 pc
B.	Legs	4 pcs

* Please make sure that you have all the parts indicated above before you begin assembly of this item.
* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
* This item may require periodic tightening**.**

Assembly Instructions

1. **Attach Legs (B)** Place the Top Assembly (A) upside down on a soft surface. Align the exposed threads of the Legs (B) with the pre-threaded holes in the Top Assembly (A). Secure the legs by turning in a clockwise direction. If the Legs (B) are out of alignment after they are tight, turn until they sit in the correct position as shown in illustration. **Note: Be careful not to over tighten the Legs (B).**
2. Put the table upright. Turn the folded top panel of Top Assembly (A) 90 degrees in a counter-clockwise direction and open the folded top panel. See illustration.